

Fitting guide for LAD-03

1. Choose a suitable place in the fence section so that the rigidity of the section is not violated by fitting the Letterbox assembly (making a hole)
2. Draw the hole for the assembly with the dimensions of the letterbox body. The hole for the assembly should be 6mm larger than the size of the letterbox body. For the correct function of the Letterbox and avoid water ingress, it is necessary to maintain horizontality
3. Cut the hole and clean the edges
4. Insert the letterbox assembly into the prepared hole so that it rests against the outside of the fence
5. To attach the assembly from the inside of the fence, we recommend using an L profile, attached with screws or rivets
6. The letterbox can be drilled in any place around the perimeter according to the depth of the fence part.
7. Use sealant to ensure no water ingress through any drilled holes in the letterbox body.